

Jamaica, NY October 4, 2021

General Notice No. 7-22

Effective 12:01 AM Monday, October 4, 2021

(A) Entire Railroad General Notices

<u>NOTE:</u> Unless otherwise indicated, ALL revisions listed below are effective at the effective date/time of the General Notice.

STATION PAGES REVISIONS

MLN Branch See Page 1, Para. (D)

MTK Branch See Pages 1 & 2, Para. (D)

PJN Branch See Page 2, Para. (D)

CEN Branch See Page 2, Para. (D)

PWS Branch See Page 2, Para. (D)

OBY Branch See Page 2, Para. (D)

ATL Branch See Page 2, Para. (D)

FRY Branch See Page 2, Para. (D)

WHD Branch See Page 2, Para. (D) LBH Branch See Pages 2 & 3, Para. (D)

HEM Branch See Page 3, Para. (D)

Secondary Tracks & Belmont Park See Page 3, Para. (D)

SPECIAL INSTRUCTION REVISIONS

5016-A-2 Tracks / Car Capacities & Johnson Ave. Yard Map See Page 3, Para. (E)

OPERATIONS MANUAL REVISIONS

Operating Rule 109 See Page 3, Para. (F)

(B) Entire Railroad

Physical Characteristics - Johnson Ave. Lead Track

In support of the Jamaica Capacity Improvement project, the Derail located at the east end of the Johnson Ave. Lead Track is out of service to be removed.

(C) Entire Railroad Mile Posts

The Mile Posts along the right of way have been verified systemwide for measurement accuracy and updated in the revised Station Pages included with this GN. As a result, the location measurements listed in the Station Pages will now conform with the Mile Posts along the right of way for ALL branches. Mile Post numbers may be used in Form L's, General Orders, General Notices, Speed Restriction Forms, Temporary Speed Restriction Bulletins, Bulletin Notices or instructions relating to train operation systemwide.

(D) Entire Railroad

Current Timetable - Station Pages

General Notice Replacement Pages III, IV, V, VI, VII & VIII.

On Page III, **MAINLINE BRANCH** Station Pages, "Distance from NY or LIC" column has been re-named, "**Location**" column and a second heading above LONG ISLAND CITY has been added.

At bottom of Mainline Branch Station Page, "* Mileage shown conforms with Mile Post locations on the right of way" has been revised to read, "Station Locations shown conform with Mile Post locations on the right of way."

On Page IV, **MONTAUK BRANCH** Station Pages, "Distance from LIC" column has been re-named, "Location" column.

General Notice: 7-22 (Paragraph (D) Continued)

The "Long Island City", "Dutch Kills Bridge" & "Bliss" rows have been removed in their entirety.

At the bottom of the Montauk Branch Station Page, "* Station Locations shown conform with Mile Post locations on the right of way" has been added.

On Page V, **PORT JEFFERSON BRANCH** Station Pages, "Distance from LIC" column has been re-named, "**Location**" column.

At bottom of Port Jefferson Branch Station Page, "* Mileage shown conforms with Mile Post locations on the right of way" has been revised to read, "Station Locations shown conform with Mile Post locations on the right of way."

On Page V, **CENTRAL BRANCH** Station Pages, "Distance from LIC" column has been re-named, "**Location**" column

At bottom of Central Branch Station Page, "* Mileage shown conforms with Mile Post locations on the right of way" has been revised to read, "Station Locations shown conform with Mile Post locations on the right of way."

On Page VI, **PORT WASHINGTON BRANCH** Station Pages, "Distance from LIC" column has been re-named, "**Location**" column

At the bottom of the Port Washington Branch Station Page, "* Station Locations shown conform with Mile Post locations on the right of way" has been added.

On page VI, **OYSTER BAY BRANCH** station pages, "Distance from LIC" column has been re-named, "**Location**" column

At bottom of Oyster Bay Branch station page, "* Mileage shown conforms with Mile Post locations on the right of way" has been revised to read, "Station Locations shown conform with Mile Post locations on the right of way."

On Page VI, **ATLANTIC BRANCH** station pages, "Distance from Atlantic Terminal" column has been re-named, "**Location**" column.

At bottom of Atlantic Branch Station Page, "* Mileage shown conforms with Mile Post locations on the right of way from Atlantic Terminal to Bolands Landing ONLY" has been changed to read, "* Station Locations shown conforms with Mile Post locations on the right of way".

On Page VII, **FAR ROCKAWAY BRANCH** Station Pages, the "Station Signals" column has been removed and the "Distance from Valley" column has been re-named, "**Location**" column.

At the bottom of the Far Rockaway Branch Station Page, "* Station Locations shown conform with Mile Post locations on the right of way" has been added.

On Page VII, **WEST HEMPSTEAD BRANCH** Station Pages, the "Station Signals" column has been removed and the "Distance from Valley" column has been re-named, "**Location**" column.

At the bottom of the West Hempstead Branch Station Page, "* Station Locations shown conform with Mile Post locations on the right of way" has been added.

On Page VII, **LONG BEACH BRANCH** Station Pages, the "Station Signals" column has been removed and the "Distance from Valley" column has been re-named, "**Location**" column.

General Notice: 7-22 (Paragraph (D) Continued)

At the bottom of the Long Beach Branch Station Page, "* Station Locations shown conform with Mile Post locations on the right of way" has been added.

On Page VII, **HEMPSTEAD BRANCH** Station Pages, the "Station Signals" column has been removed and the "Distance from LIC" column has been re-named, "**Location**" column.

At the bottom of the Hempstead Branch Station Page, "* Station Locations shown conform with Mile Post locations on the right of way" has been added.

On Page VIII, **GARDEN-MITCHEL FIELD** Station Pages, the "Station Signals" column has been removed and the "Distance from Garden" column has been re-named, "**Location**" column.

On Page VIII, **BABYLON-BABYLON YARD** Station Pages, the "Station Signals" column has been removed and the "Distance from Babylon" column has been re-named, "**Location**" column.

On Page VIII, SECONDARY TRACK "C", LIRR SECONDARY NO 1 AND NO 2 TRACKS & NYAR SECONDARY NO 1 AND NO 2 Station Pages, the "Distance from LIC" column has been re-named, "Location" column.

On Page VIII, **BELMONT PARK** Station Pages, the "Distance from Queens" column has been re-named, "**Location**" column.

(E) Entire Railroad

Timetable Special Instruction 5016-A-2

General Notice Replacement Pages I-201 & I-202

On Page I-201, "Johnson Ave. Lead" description and location revised to read as follows:

"Johnson Ave. Lead is south of 11 track and is protected by an eastbound low home controlled by JCC (HW)"

On Page I-202, "Johnson Ave. Yard Map" has been revised to reflect no derail at the east end of Johnson Ave. Lead track.

(F) Entire Railroad

Operations Manual – Rules of The Operating Department Employees must make the following change in ink:

On Page 51, Rule 109, place an "X" through the entire 2nd paragraph.

GO 702 III

GO 70)2							III
						MAIN LINE		
						BRANCH *		Siding
								Car
	Inter-		Block	Pass-		STATIONS		Capacity
Inter-	locking	Block	Limit	enger	Radio	(PSCC TO HAROLD)		85 ft.
locking	Station	Station	Station	Station	Equipped		Location	Cars
	Х				CH 1	PSCC	0.3	
XR						A R- From PSCC	0.2	
XR						KN R- From PSCC	0.1	
				X	CH 1	NEW YORK	0.0	
XR						JO R- From PSCC	0.1	
XR XR						F R- From PSCC	0.1 3.0	
XR						HAROLD R- From PSCC	3.7	
XIX							5.7	
						MAIN LINE		
						BRANCH *		Siding
				_		CTATIONS		Car
1-1	Inter-	Dissi	Block	Pass-	D - di-	STATIONS		Capacity
Inter- locking	locking Station	Block Station	Limit Station	enger Station	Radio Equipped	(LIC TO GREENPORT)	Location	85 ft. Cars
	Otation			X		LONG ISLAND CITY	0.0	
				X		HUNTERSPOINT AVE	0.6	
XR						HAROLD R- From PSCC	1.8	
				Х		WOODSIDE	3.1	
XR						WOOD R- From Jamaica	3.2	
				X		FOREST HILLS	6.7	
				Х		KEW GARDENS	7.7	
XR					CH 1 CH 1&3	JAY R - From JCC JCC	9.0	
	X				CH 1&3	JAMAICA	9.3 9.3	
XR					CH 1	HALL R - From JCC	9.4	
						HILLSIDE - Employees only	11.0	
				X		HOLLIS	11.5	
XR						HOLLIS R- From JCC	11.6	
				Х		QUEENS VILLAGE	13.2	
XR					CH 1	QUEENS R- From JCC	13.3	
				X		FLORAL PARK	14.9	
				X		NEW HYDE PARK	16.2	
XR					CH 1	MERILLON AVE NASSAU 1 R- From JCC	17.3 17.4	
						MINEOLA	18.5	
XR		X			CH 1	NASSAU 2 R- From JCC	18.6	
XR					CH 1	NASSAU 3 R- From JCC	19.8	
				Х		CARLE PLACE	20.4	
				Х		WESTBURY	21.4	
				Х		HICKSVILLE	24.8	
XR					CH 3	DIVIDE R- From JCC	24.9	
XR				X		BETHPAGEBETH R- From JCC	27.9 28.6	
				χ		FARMINGDALE	30.2	
XR						FARM R- From JCC	30.3	
XR						PW R- From JCC	31.5	
XR						LAWN R-From JCC	32.3	
				Х		PINELAWN	32.4	
XR						DANCH R-From JCC	34.1	
				Х		WYANDANCH	34.7	
XR						JS R- From JCC	37.9	
XR						DEER PARK PILGRIM R- From JCC	38.4 38.7	
XR						PINEAIRE R- From JCC	39.7	
				X		BRENTWOOD	41.1	
XR						CI R- From JCC	42.8	
				Х		CENTRAL ISLIP	43.6	
XR						OCEAN R- From JCC	47.6	
XR						POND R- From JCC	47.9	
				Х		RONKONKOMA	48.5	
XR		Х			RT	KO R- From JCC	49.4	
				X	RT	MEDFORDYAPHANK	54.1 58.6	
			Χ			YA C-JCC	58.7	22
			X			MR C-JCC	65.1	
			X			AH C-JCC	69.4	19
				Х	RT	RIVERHEAD	73.3	
			Х			LD C-JCC	73.4	27
			Х			R C-JCC	78.3	
				Х		MATTITUCK	82.4	
			X			K C-JCC	82.4	14
			X		RT	SD C-JCC SOUTHOLD	90.1 90.1	
			Χ			GY C-JCC	93.6	
	1		_ ^			1	55.0	

NOTE: X

GN 7-22 (D)

Indicates in service continuously

С Controlled

R Indicates Remote Controlled

СН Indicates Radio Equipped and Channel RT Indicates Equipped with Radio telephone; see Special Instruction MLN 1164 B

for exact location.

Station Locations shown conform with Mile Post locations on the right of way

**Cars must not be left standing on passing sidings

IV GO 702

Montauk Black Black Limit Pass-toking Station Statio	IV		1	ı					0 702
Inter- I									
Inter-							BRANCH*		-
							STATIONS		
X								Location	
Name							IAMAICA		
X					X				
X									
X	X	X	Х			CH 1		15.8	
RR					1 "			• • •	
X									
X									
RR							FREEPORT		
X									
X				l .	Х				
XR								-	
X					Х				
X									
XR				l .					
XR	XR							-	
XR				l .	, ,				
X	XR			l .			AMITYVILLE R- From Babylon		
X							AMITYVILLE		
X							COPIAGUE		
X									
X					Х				
X					×				
X									
XR							GREAT RIVER		
XR								46.7	
XR					X				
XR									
PD 2 R-From Babylon			/ /						
Name									
X									
XR					Х		BELLPORT	57.9	13
XR					X			61.5	
XR									C-16
XR									
XR									
XR				l .				-	
XR									
XR							RPK 1 R- From Babylon		
RPK3 R-From Babylon	XR								
Name				l .					
Name									
XR				l .					
Name									
Indicates in service continuously C C C Indicates Radio Equipped and Channel				l .					
X RT AMAGANSETT R-From Babylon 103.7 17 114.9									
IOTE: X Indicates in service continuously C Controlled R Indicates Interlocking Remote Controlled CH Indicates Radio Equipped and Channel Indicates Equipped with Radio telephone; see Special Instruction MTK 1164 B for exact location. * Station Locations shown conform with Mile Post locations on the right of way. **Cars must not be left standing on passing sidings without notifying Train Dispatcher.									
IOTE: X Indicates in service continuously C Controlled R Indicates Interlocking Remote Controlled CH Indicates Radio Equipped and Channel RT Indicates Equipped with Radio telephone; see Special Instruction MTK 1164 B for exact location. * Station Locations shown conform with Mile Post locations on the right of way. **Cars must not be left standing on passing sidings without notifying Train Dispatcher.				l .					
Indicates in service continuously C Controlled R Indicates Interlocking Remote Controlled CH Indicates Radio Equipped and Channel RT Indicates Equipped with Radio telephone; see Special Instruction MTK 1164 B for exact location. * Station Locations shown conform with Mile Post locations on the right of way. **Cars must not be left standing on passing sidings without notifying Train Dispatcher.					Х	RT		114.9	
C Controlled R Indicates Interlocking Remote Controlled CH Indicates Radio Equipped and Channel RT Indicates Equipped with Radio telephone; see Special Instruction MTK 1164 B for exact location. * Station Locations shown conform with Mile Post locations on the right of way. **Cars must not be left standing on passing sidings without notifying Train Dispatcher.	NOTE:		Indicates	in conde	oontinger	John John John John John John John John	I(K- From Babylon)		l .
R Indicates Interlocking Remote Controlled CH Indicates Radio Equipped and Channel RT Indicates Equipped with Radio telephone; see Special Instruction MTK 1164 B for exact location. * Station Locations shown conform with Mile Post locations on the right of way. **Cars must not be left standing on passing sidings without notifying Train Dispatcher.	NO IE:				; continuot	uoiy			
CH Indicates Radio Equipped and Channel RT Indicates Equipped with Radio telephone; see Special Instruction MTK 1164 B for exact location. * Station Locations shown conform with Mile Post locations on the right of way. **Cars must not be left standing on passing sidings without notifying Train Dispatcher.					na Remot	- Controllo	d		
RT Indicates Equipped with Radio telephone; see Special Instruction MTK 1164 B for exact location. * Station Locations shown conform with Mile Post locations on the right of way. **Cars must not be left standing on passing sidings without notifying Train Dispatcher.							u		
for exact location. * Station Locations shown conform with Mile Post locations on the right of way. **Cars must not be left standing on passing sidings without notifying Train Dispatcher.							e: see Special Instruction MTK	1164 R	
* Station Locations shown conform with Mile Post locations on the right of way. **Cars must not be left standing on passing sidings without notifying Train Dispatcher.		13.1			willi ivaui	io reiehi ioi	e, see opecial instruction with	1104 D	
Mile Post locations on the right of way. **Cars must not be left standing on passing sidings without notifying Train Dispatcher.			ioi exact		n Locatio	ns show	n conform with		
**Cars must not be left standing on passing sidings without notifying Train Dispatcher.									
without notifying Train Dispatcher.			**Care					I	
		40/4/04		without	iomynig		распет.		C O 700

GO 702 V

								•
						PORT JEFFERSON		
						BRANCH *		Siding
								Car
	Inter-		Block	Pass-		STATIONS		Capacity
Inter-	locking	Block	Limit	enger	Radio	OTATIONS		85 ft.
locking	Station	Station	Station	Station	Equipped		Location	Cars
XR				Jialion	CH 3	DIVIDE R- From JCC	24.9	
				x		SYOSSET	29.1	
XR						AMOTT R- From JCC	30.2	
				Χ		COLD SPRING HARBOR	30.2	
XR						HUNT 1 R- From JCC	34	
XR						HUNT 2 R- From JCC	34.5	
						HUNTINGTON	34.9	
XR						HUNT 3 R- From JCC	35	41
				X		GREENLAWN	37.6	
******				Х		NORTHPORT	39.6	27777
XR						DUKE 1 R- From JCC		C-27
XR						DUKE 2 R- From JCC	40.2	
XR						FOX 1 R- From JCC	43.3	
				X		KINGS PARK	43.4	C-22
XR						FOX 2 R- From JCC	43.6	
XR						POST 1 R- From JCC	46.9	
				X		SMITHTOWN	47.1	C-24
XR						POST 2 R- From JCC	47.3	
				X		ST. JAMES	49.9	
XR						STONY 1 R- From JCC	52.9	
				X		STONY BROOK	53.1	C-18
XR						STONY 2 R- From JCC	53.3	
XR						JEFF R- From JCC	57	
				X		PORT JEFFERSON	57.4	

NOTE: X
C
R
CH Indicates in service continuously

Controlled

Indicates Interlocking Remote Controlled Indicates Radio Equipped and Channel

> * Station Locations shown conform with Mile Post locations on the right of way.

Cars must not be left standing on passing sidings without notifying Train Dispatcher.

							CENTRAL BRANCH *		Siding Car
	Inter- locking	Inter- locking Station	Block Station	Block Limit Station	Pass- enger Station	Radio Equipped	STATIONS	Location	Capacity 85 ft. Cars
1	XR 	 X	 X		 X	CH 1	BETH R- From JCCBABYLON BABYLON	28.6 36 36.6	
J	NOTE:	X R CH	Indicates	Interlockir Radio Equal * Station	Location	e Controlle d Channel s shown o	d conform with ight of way.		

Effective 10/04/21

GN 7-22

G.O. 702

VI GO 702

								0 702	
						PORT WASHINGTON BRANCH*		Siding	
						Divitori		Car	
	Inter-		Block	Pass-		STATIONS		Capacity	İ
nter- ocking	locking Station	Block Station	Limit Station	enger Station	Radio Equipped		Location	85 ft. Cars	
XR						HAROLD R- From PSCC	1.8		İ
XR				Х		WOODSIDE	3.1 3.2		
XR						SHEA R- From Jamaica	6.2		
				X		METS - WILLETS POINT	6.8		
				X		FLUSHING MAIN STREET MURRAY HILL	7.4 8.4		İ
				X		BROADWAY	9.1		
				X		AUBURNDALE	9.8		GN 7-2: (D)
XR				X		BAYSIDE BAY R - From Jamaica	10.8 11		L ` '
				X		DOUGLASTON	12		İ
				X		LITTLE NECK	12.7		
XR				X		GREAT NECK NECK R- From Jamaica	13.7 13.9		İ
				Х		MANHASSET	15.3		İ
				X		PLANDOME PORT WASHINGTON	16.3 18.1		İ
				^		R- From Jamaica	10.1		İ
NOTE:	Х	Indicates	in service	continuo	usly				İ
	R				e Controlle	d			İ
	CH	Indicates			d Channel	onform with			İ
						ight of way.			İ
				1000000		OYSTER BAY			
	1					BRANCH *		Siding	l
	1							Car	l
Intor	Inter-	Block	Block	Pass-	Radio	STATIONS		Capacity	i
nter- ocking	locking Station	Station	Limit Station	enger Station	Equipped		Location	85 ft. Cars	İ
coming	Otation	Otation	Otation	Otdion	Equippod		Location	- Cuio	İ
XR XR		X			CH 1 CH 1	NASSAU 2 R - From JCC NASSAU 4 R - From JCC	18.6 19.3		i
					CH I	EAST WILLISTON	19.3		İ
				Х		ALBERTSON	20.9		GN 7-2
				X X		ROSLYN GREENVALE	22.2 24.2		(D)
				x		GLEN HEAD	25.4		
				X		SEA CLIFF	26.8		İ
				X		GLEN STREETGLEN COVE	27.3 27.9		İ
				X		LOCUST VALLEY	29		İ
VD						LOCUST R - From JCC	29.1		İ
XR		X		V			20.0		
		X		Х		OYSTER BAY R - From JCC	32.9		
		Х		X continuo		R - From JCC	32.9		
	X R	X Indicates Indicates	in service Interlocki	continuo ng Remot	usly e Controlle	R - From JCC	32.9		
	X	X Indicates Indicates	in service Interlocki Radio Eq	continuo ng Remot uipped an	usly e Controlle d Channel	R - From JCC	32.9		
	X R	X Indicates Indicates	in service Interlocki Radio Eq * Station	continuo ng Remot uipped an Location	usly e Controlle d Channel is shown c	R - From JCCd	32.9		
	X R	X Indicates Indicates	in service Interlocki Radio Eq * Station	continuo ng Remot uipped an Location	usly e Controlle d Channel is shown c	R - From JCC	32.9		
	X R	X Indicates Indicates	in service Interlocki Radio Eq * Station	continuo ng Remot uipped an Location	usly e Controlle d Channel is shown c	R - From JCCd conform with ight of way.	32.9	Siding	
	X R CH	X Indicates Indicates	in service Interlocki Radio Eq * Station Mile Pos	e continuo ng Remot uipped an Location	usly e Controlle d Channel is shown c	R - From JCCd conform with ight of way. ATLANTIC BRANCH *	32.9	Siding Car	
NOTE:	X R CH	Indicates Indicates Indicates	in service Interlocki Radio Eq * Station Mile Pos	e continuo ng Remoti uipped an Location ti location	usly e Controlle d Channel is shown on	R - From JCCd conform with ight of way. ATLANTIC	32.9	Siding Car Capacity	
NOTE:	X R CH	X Indicates Indicates	in service Interlocki Radio Eq * Station Mile Pos	e continuo ng Remot uipped an Location	usly e Controlle d Channel is shown on s on the r	R - From JCCd conform with ight of way. ATLANTIC BRANCH *	32.9	Siding Car Capacity 85 ft.	
NOTE:	X R CH	X Indicates Indicates Indicates	in service Interlocki Radio Eq * Station Mile Pos Block Limit	e continuo ng Remot uipped an Location to location	usly e Controlle d Channel is shown o is on the r Radio Equipped	R - From JCCd conform with light of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL	Location 0.0	Siding Car Capacity 85 ft.	
nter-ocking	X R CH	X Indicates Indicates Indicates Indicates Indicates	in service Interlocki Radio Eq * Station Mile Pos Block Limit Station	e continuo ng Remot uipped an Location st location Pass- enger Station X	usly e Controlle d Channel s shown c as on the r Radio Equipped CH 1	R - From JCCd conform with ight of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL	Location 0.0 0.2	Siding Car Capacity 85 ft. Cars	
NOTE:	X R CH	X Indicates Indicates Indicates Indicates Indicates	in service Interlocki Radio Eq * Station Mile Pos Block Limit Station	e continuo ng Remot uipped an Location at location Pass- enger Station X	usly e Controlle d Channel is shown o is on the r Radio Equipped	R - From JCCd conform with light of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL	Location 0.0	Siding Car Capacity 85 ft. Cars	
NOTE:	X R CH	X Indicates Indicates Indicates Block Station	in service Interlocki Radio Eq * Station Mile Pos Block Limit Station	Passenger Station X X X	Radio Equipped CH 1 CH 1 CH 1 CH 1 CH 1 CH 1	R - From JCCd conform with ight of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL BROOK 1 BROOK 2 BROOK 2 STATIONS ATLANTIC TERMINAL BROOK 2 STATIONS	Location 0.0 0.2 0.6 1.6 3.9	Siding Car Capacity 85 ft. Cars	
NOTE:	Inter-locking Station	X Indicates Indicates Indicates Indicates	in service Interlocki Radio Eq * Station Mile Pos Block Limit Station	Passenger Station X	Radio Equipped CH 1	R - From JCCd d conform with ight of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL BROOK 1 BROOK 2 NOSTRAND AVENUE EAST NEW YORK EAST NEW YORK	Location 0.0 0.2 0.6 1.6	Siding Car Capacity 85 ft. Cars	
nter-ocking X X	X R CH	X Indicates Indicates Indicates Block Station	in service Interlocki Radio Eq * Station Mile Pos Block Limit Station	Passenger Station X X X	Radio Equipped CH 1 CH 1 CH 1 CH 1 CH 1 CH 1	R - From JCCd conform with ight of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL BROOK 1 BROOK 2 NOSTRAND AVENUE EAST NEW YORK R - From Brook BOLANDS LANDING Emp	Location 0.0 0.2 0.6 1.6 3.9	Siding Car Capacity 85 ft. Cars	GN 7-2: (D)
nter- ocking X X X XR	Inter-locking Station	X Indicates Indicates Indicates Indicates	in service Interlocki Radio Eq * Station Mile Pos Block Limit Station	Passenger Station X X X X X	Radio Equipped CH 1 CH 1 CH 1 CH 1	R - From JCCd d conform with ight of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL BROOK 1 BROOK 2 NOSTRAND AVENUE EAST NEW YORK R - From Brook BOLANDS LANDING Emp. DUNTON R - From JCC	Location 0.0 0.2 0.6 1.6 3.9 4 8.5 8.7	Siding Car Capacity 85 ft. Cars	
nter- ocking X X XR XR	X R CH	X Indicates Indicates Indicates Indicates	In service Interlockic Radio Eq. * Station Mile Pos	Passenger Station X X X X	Radio Equipped CH 1 CH 1 CH 1	R - From JCCd conform with ght of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINALBROOK 1 BROOK 2 NOSTRAND AVENUEBROOK 2 NOSTRAND AVENUEBAST NEW YORKR - From Brook BOLANDS LANDING EmpDUNTON R - From JCC. JAY R - From JCC. JAY R - From JCC.	Location 0.0 0.2 0.6 1.6 3.9 4 8.5 8.7 9	Siding Car Capacity 85 ft. Cars	
nter- ocking X X X XR	Inter-locking Station	X Indicates Indicates Indicates Indicates	in service Interlocki Radio Eq * Station Mile Pos Block Limit Station	Passenger Station X X X X X	Radio Equipped CH 1 CH 1 CH 1 CH 1	R - From JCCd d conform with ight of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL BROOK 1 BROOK 2 NOSTRAND AVENUE EAST NEW YORK R - From Brook BOLANDS LANDING Emp. DUNTON R - From JCC	Location 0.0 0.2 0.6 1.6 3.9 4 8.5 8.7	Siding Car Capacity 85 ft. Cars	
nter- ocking X XR XR XR	Interlocking Station X X R CH Interlocking Station X X X	X Indicates Indicates Indicates Indicates	In service Interlockic Radio Eq. * Station Mile Pos	Passenger Station X X X X X X X X X X X X X X X X X X X	Radio Equipped CH 1 CH 1 CH 1 CH 1 CH 1 CH 1 CH 1 CH 1	R - From JCCd conform with ght of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINALBROOK 1 BROOK 2 NOSTRAND AVENUEBROOK 2 NOSTRAND AVENUER - From Brook BOLANDS LANDING Emp DUNTON R - From JCC. JAY R - From JCC. JAY R - From JCC. JAMAICAHALL R - From JCC.	Location 0.0 0.2 0.6 3.9 4 8.5 8.7 9 9.3 9.3 9.3 9.4	Siding Car Capacity 85 ft. Cars	
nter-ocking X X XR XR XR XR XR	Interlocking Station X X R CH Interlocking Station X X X	Block Station	In service Interlocking Radio Eq. * Station Mile Pos Block Limit Station	Passenger Station X X X X X X X X X X X X X X X X X X X	Radio Equipped CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH	R - From JCC d conform with light of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL BROOK 1 BROOK 2 NOSTRAND AVENUE EAST NEW YORK EAST NEW YORK R - From Brook BOLANDS LANDING Emp DUNTON R - From JCC JAY R - From JCC JAMAICA HALL R - From JCC LOCUST MANOR	Location 0.0 0.2 0.6 3.9 4 8.5 8.7 9 9.3 9.3 9.4 12	Siding Car Capacity 85 ft. Cars	
nter- ocking X XR XR XR	Interlocking Station X X R CH Interlocking Station X X X	X Indicates Indicates Indicates Indicates	In service Interlockic Radio Eq. * Station Mile Pos	Passenger Station X X X X X X X X X X X X X X X X X X X	Radio Equipped CH 1 CH 1 CH 1 CH 1 CH 1 CH 1 CH 1 CH 1	R - From JCCd conform with ght of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINALBROOK 1 BROOK 2 NOSTRAND AVENUEBROOK 2 NOSTRAND AVENUER - From Brook BOLANDS LANDING Emp DUNTON R - From JCC. JAY R - From JCC. JAY R - From JCC. JAMAICAHALL R - From JCC.	Location 0.0 0.2 0.6 3.9 4 8.5 8.7 9 9.3 9.3 9.3 9.4	Siding Car Capacity 85 ft. Cars	
nter-ocking X X XR XR XR XR XR XR XR XR X	Inter-locking Station X	Block Station	in service Interlocki Radio Eq * Station Mile Pos Block Limit Station	Passenger Station X X X X X X X X	Radio Equipped CH 1 CH 1 CH 1 CH 1 CH 1 CH 1 CH 1 CH	R - From JCC d conform with light of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL BROOK 1 BROOK 2 NOSTRAND AVENUE EAST NEW YORK EAST NEW YORK EAST NEW YORK From Brook BOLANDS LANDING Emp DUNTON R - From JCC. JCC JCMANCA FROM JCC. JCC JCMANCA LANDING EMP DUNTON R - From JCC. JCC LOCUST MANOR LAURELTON ROSEDALE VALLEY STREAM	Location 0.0 0.2 0.6 3.9 4 8.5 8.7 9 9.3 9.3 9.4 12 13.1 13.8 15.7	Siding Car Capacity 85 ft. Cars	
Inter-locking X X XR XR XR XR XX XX	Inter-locking Station X X R CH Inter-locking Station X X X X X	Block Station	in service Interlocki Radio Eq. * Station Mile Pos Block Limit Station	Passenger Station X X X X X X X X X X X X X X X X X X X	Radio Equipped CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1	R - From JCCd conform with ght of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL BROOK 1 BROOK 2 NOSTRAND AVENUE EAST NEW YORK	Location 0.0 0.2 0.6 1.6 3.9 4 8.5 8.7 9 9.3 9.3 9.4 12 13.1 13.8	Siding Car Capacity 85 ft. Cars	
nter-ocking X X XR XR XR XR XR XR XR XR X	Inter-locking Station X	Block Station	Block Limit Station	Passenger Station X X X X X X X X X X X X X X X X X X X	Radio Equipped CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1	R - From JCCd d conform with ight of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL BROOK 1 BROOK 2 NOSTRAND AVENUE EAST NEW YORK EAST NEW YORK R - From Brook BOLANDS LANDING Emp DUNTON R - From JCC. JAY R - From JCC JAY R - From JCC LOCUST MANOR LAURELTON ROSEDALE VALLEY STREAM VALLEY	Location 0.0 0.2 0.6 3.9 4 8.5 8.7 9 9.3 9.3 9.4 12 13.1 13.8 15.7	Siding Car Capacity 85 ft. Cars	
nter- ocking X X XR XR XR XR XX	Interlocking Station X X R CH Interlocking Station X X X X X	Block Station	in service Interlocki Radio Eq. * Station Mile Pos Block Limit Station in service Interlocki Radio Eq.	Passenger Station X X X X X X X X X X X X X X X X X X X	Radio Equipped CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1 CH1	R - From JCC	Location 0.0 0.2 0.6 3.9 4 8.5 8.7 9 9.3 9.3 9.4 12 13.1 13.8 15.7	Siding Car Capacity 85 ft. Cars	
Inter-locking X X XR XR XR XR XX XX	Interlocking Station X X X X X X X R	Block Station	Block Limit Station in service * Station Mile Pos Block Limit Station in service Interlocki Radio Eq. * Station	Passenger Station X X X X X X X X X X X X X X X X X X X	Radio Equipped CH 1 CH 1 CH 1 CH 1 CH 1 CH 1 CH 1 CH	R - From JCCd d conform with ight of way. ATLANTIC BRANCH * STATIONS ATLANTIC TERMINAL BROOK 1 BROOK 2 NOSTRAND AVENUE EAST NEW YORK EAST NEW YORK R - From Brook BOLANDS LANDING Emp DUNTON R - From JCC. JAY R - From JCC JAY R - From JCC LOCUST MANOR LAURELTON ROSEDALE VALLEY STREAM VALLEY	Location 0.0 0.2 0.6 3.9 4 8.5 8.7 9 9.3 9.3 9.4 12 13.1 13.8 15.7	Siding Car Capacity 85 ft. Cars	GN 7-22 (D)

GO 702 VII

	GO 70)2							VII
		Inter-		Block	Pass-		FAR ROCKAWAY BRANCH* STATIONS		Siding Car Capacity
	Inter-	locking	Block	Limit	enger	Radio		Location	85 ft.
GN 7-22 (D)	X	X	X	Station	Station X X X X X X X	CH 1	VALLEY GIBSON HEWLETT WOODMERE CEDARHURST LAWRENCE INWOOD FAR ROCKAWAY (R - Valley)	15.8 16.2 16.9 17.3 18.2 19 19.4 20	Cars
	NOTE	X CH R	Indicates	Radio Eq Interlocki	continuous uipped and ng Remote	Channel Controlled			
							conform with		
				Mile Po	st locatio	ns on the i	right of way.		
							WEST HEMPSTEAD BRANCH*		Siding Car
	Inter- locking	Inter- locking Station	Block Station	Block Limit Station	Pass- enger Station	Radio Equipped	STATIONS	Location	Capacity 85 ft. Cars
GN 7-22 (D)	X	X	X		X X X X	CH 1	VALLEY WESTWOOD MALVERNE LAKEVIEW HEMPSTEAD GARDENS WEST HEMPSTEAD (R - Valley) WEST HEMPSTEAD	15.8 16.8 17.7 18.8 19.5 20	
	NOTE	X CH R	Indicates	Radio Eq Interlocki * Station		Channel Controlled as shown o	conform with		
							LONG BEACH BRANCH*		Siding Car
	Inter- locking	Inter- locking Station	Block Station	Block Limit Station	Pass- enger Station	Radio Equipped	STATIONS	Location	Capacity 85 ft. Cars
GN 7-22 (D)	X	X	X		X X X X X		VALLEY LYNBROOK CENTRE AVENUE EAST ROCKAWAY OCEANSIDE ISLAND PARK LEAD LONG BEACH	15.8 17 17.9 18.3 18.9 21.3 21.7 22.2	
	NOTE	X			ce continuo				
		CH	indicate			nd Channe is shown o	onform with		
							right of way.		
							HEMPSTEAD BRANCH*		Siding Car
	Inter- locking	Inter- locking Station	Block Station	Block Limit Station	Pass- enger Station	Radio Equipped	STATIONS	Location	Capacity 85 ft. Cars
GN 7-22 (D)	XR XR				X X X X X X	CH 1	QUEENS -R From JCC BELLEROSE FLORAL PARK STEWART MANOR NASSAU BOULEVARD GARDEN CITY GARDEN R-JCC COUNTRY LIFE PRESS HEMPSTEAD	13.3 14.3 14.9 16.2 17.2 18.4 18.6 19	
	NOTE	X CH R	Indicates	s Radio E Interlocki	ng Remote	nd Channe Controlled			
							conform with		
	Effective	10/04/21		wille PC	oursion received	GN 7-22	right of way.		G.O. 702

VIII							G	O 702
			SEC	_	Y TRACK STATION ELMONT YARD	IS		
					GARDEN-MITCHEL FIELD		Siding Car	
Inter- ocking	Inter- locking Station	Block Station	Block Limit Station	Radio Equipped	SECONDARY TRACK	Location	Capacity 85 ft. Cars	GN7- (D)
XR					GARDEN (R - JCC)	18.6 20.6		
			1					
					BABYLON BABYLON YARD		Siding	
Inter-	Inter- locking	Block	Block Limit	Radio	SECONDARY TRACK		Car Capacity 85 ft.	GN 7- (D)
locking X	Station	Station	Station	Equipped CH 1	BABYLON	Location 36	Cars	
				CH 4	BABYLON YARD	36.5		
				SECO	NDARY TRACK "C"			
	L.I. CITY						Location 0.0	
	DUTCH F	KILLS BRID	DARY TRA DGE ARY TRACI				0.1 0.7 1.2	
			LIRR S	ECONDA	RY NO 1 AND NO 2 TRAC	KS		
	BEGIN L	IRR SECO	NDARY TF	RACK			Location 7.39	
	JAY R JO	CC					8.7	GN 7- (D)
			NY	AR SECC	NDARY NO 1 AND NO 2			
							Location	
				TRACK BLI RACK SIGN			1.2 7.39	
				ВЕ	LMONT YARD			
				ВЕ	LMONT PARK			
			ICC				13.3 13.4	
	QUEENS						13.4	J
NOTE		IT PARK	es in serv	ice continu	uously		13.4	

5016

GN 7-22 (E)

JOHNSON AVE. YARD

Located South of 11 Track Jamaica

5016-A-1 Maximum Authorized Speed - Yard

Restricted speed not exceeding 10 MPH.

Freight: Restricted speed not exceeding 5 MPH, unless otherwise specified.

5016-A-2 Tracks / Car Capacities

Tracks: Tracks 1-4 (North to South)

 -Johnson Ave. Lead is south of 11 track and is protected by an eastbound low home controlled by JCC (Hw)

•Armour siding is an eastbound trailing point hand operated switch on the Johnson Ave. Lead (only hand operated switch in Jamaica) No third rail.

Car Capacities: Tracks 1 & 2: 10 cars Tracks 3 & 4: 12 cars

5016-A-3 Third Rail - DC Electrified Operation

Tracks 1-4

5016-A-4 Switches

Automatic Safety Switches

5016-A-7 Communications

Jamaica Yardmaster (Yard 1) can be reached via Channel 1 or at ext. (8318).

5016-A-8 Bulletin Board, Standard Clock, Electronic Delivery of Written Mandatory Directives – Location

Jamaica Trainmen's Room

5016-B-1 Authority to Occupy Johnson Ave. Lead

Permission from Yard 1 is needed to occupy Johnson Avenue lead and enter the yard.

5016-D-1 Switching Movements

All automatic safety switches must be cleared when performing yard switching movements. Employees must comply with all other applicable rules and/or special instructions when performing yard switching movements.

5016-D-2 Drill Movements

Into or out of Johnson Avenue Yard, two (2) or four (4) car drill moves are prohibited unless the Yardmaster on duty receives verbal authorization from Transportation Supervision.

5016-H-3 Equipment Positioning Signs

Equipment Positioning Signs are in service at the west end of Johnson Avenue yard approximately thirty-five feet east of the bumper blocks on tracks 3 and 4 to assist in the proper positioning of equipment. Equipment should be placed with this Sign alongside the side window of the operating compartment of the west unit.

5016-M Close Clearance Conditions Exist

On Johnson Ave. Lead and the South side of Yard Track 4 and crews using facility are advised to use caution.

Effective 10/04/21 GN 7-22 G.O. 702

